



Process Intensification for Chemical Manufacturing using Continuous Flow Processing

Christian Hornung | Senior Research Scientist – Director, Centre for Industrial Flow Chemistry
31 May 2017

CSIRO MANUFACTURING
www.csiro.au

RSC Symposium: Continuous Flow Chemistry for Industrial Processes 2017
Chemspec Europe - Munich



Continuous Flow Processing at CSIRO – Lab Discovery

Vapourtec - Tubular Reactor Systems



Zaiput L-L Separators



Partners / Suppliers:

CHEMTRIX

vapourtec

CRD CAMBRIDGE
REACTOR DESIGN

Zaiput Flow Technologies
Groundbreaking Innovations in Flow Chemistry

UNIQSIS
Accessible flow chemistry

Chip & Tubular Reactor Modules



Uniqsis –
Flow Reactors



Capabilities:


- Hom. Liquid Phase
- Liquid-Liquid
- Gas-Liquid
- Het. Catalysis
- (Slurry Reactions)

Continuous Flow Processing at CSIRO – Scale-up

CRD Shell & Tube Reactors



up to 2 L reactor volume
→ up to >2500 L/day



ChemTrix
Plate type Reactor

CSIRO Tubular Flow Reactor




FloWorks – CSIRO's Centre for Industrial Flow Chemistry

The **Centre for Industrial Flow Chemistry**, based in Clayton, is a technology platform providing access to CSIRO's flow chemistry technology to chemical manufacturers. → **from lab discovery to scale-up and production**


Services:

- process R&D operations for industrial clients
- managing the technology transfer to client site
- in-house training for industrial collaborators
- innovative research on new process technology for chemical manufacture


CHEMICAL
DISCOVERY



REACTION
OPTIMISATION




PROCESS
SCALE-UP




launched on 22nd November 2016

Project areas:



FloWorks – New Facility at Clayton, VIC



Partners:

- Academia (Monash, Deakin, ...)
- Equipment Manufacturers (Cambridge Reactor Design, Chemitrix, ...)
- Chemical Manufacturers (Boron Molecular, ...)
- VCSCM, Chemistry Australia, ...




- ➔ operation of **laboratory scale** and **industrial scale** flow chemistry equipment
- ➔ accommodating **current** operations and development of **new** flow chemistry solutions

Recent commercial projects include...

- **Emulsion polymerisation**
slow reaction, low temperature, high viscosity, intensified mixing required
- **Synthesis of polymers with very narrow polydispersity**
fast reaction, SM difficult to handle, very precise process control needed
- **Synthesis of novel monomers**
exothermic reaction, moisture sensitive compounds

Space Time Yield

$$STY = \frac{\text{Product}}{t_P \cdot V_R}$$







Process Improvements:

	Reaction Time		Space Time Yield [g L ⁻¹ h ⁻¹]	
	batch	flow	batch	flow
• Synthesis of RAFT precursor	8 h	10 min	0.69	768
• Synthesis of dye intermediate	n/a	30 min	7.6	235
• Synthesis of API precursor	7 d	10 min	0.44	1336


Carbohydrates as Renewable Feedstock




Biomass




Bulk Chemicals & Biofuel



HMF
(5-(hydroxymethyl)furfural)




CMF
(5-(chloromethyl)furfural)



LA
(levulinic acid)

Continuous Flow Dehydration of Sugar




By-Product: HUMIN






- aqueous + organic → biphasic flow
- very short residence times: ~1 min
- moderate temperatures: ~100 °C
- inline filtration to remove by-product
- simple and efficient purification by liquid-liquid extraction

Lab-Scale: 10 ml tubular reactor




Vapourtec R2/R4 reactor system

CMF from High Fructose Corn Syrup (HFCS) using Flow



CMF as a renewable platform chemical



Bio-refinery Concept for CMF

using lignocellulosic or sugar-based feedstocks from:

- Agricultural waste
- Food waste
- Refined renewable feed stocks (sucrose, HFCS)




... towards a chemical industry using renewable resources

Scale-up of the RAFT Process

RAFT: Reversible **A**ddition-**F**ragmentation **C**hain **T**ransfer




Tubular Flow Reactor
with static mixers
(reactor volume 108 ml)





Benefits of RAFT polymerisation:

- ‘Tailored’ molecular weight ($M_n \sim$ moles RAFT agent)
- Narrow mol. weight distribution
- Access to complex architectures: blocks, grafts, stars,...
- Conjugation to reactive molecules (drugs, biomolecules, etc.)




Reactor system:
Vapourtec - R2/R4
SS - 10 ml coils

Scale-up of the RAFT Process



Temperature Profiles:



Problems with scale-up in batch:

- temperature gradients
- concentration gradients
- dead zones
- inefficient mixing





small 'ideal'
system
Laboratory





large 'non-ideal'
system
Industry


Surfactants from Renewable Feedstock




+



Continuous Flow Process
100 – 160 °C





Surfactant for use in household products,
e.g. as stain remover for expensive
garments (wedding dresses and others)



Hydrogenation – Industrial Processes and a New Approach

Heterogeneous catalysis - current state of the art:




slurry – stirred tank

heterogeneous catalyst




Pd/C



fixed or fluidised bed

Our approach:

- continuous flow process
- tubular reactor system with inserts
➔ favorable flow / processing conditions
- heterogeneous catalyst supported on tubular inserts using metal deposition methods
- 3D metal printing for manufacture of inserts
- optimize fluid flow and heat and mass transfer by custom designed static mixer inserts and evaluate by CFD & EFD



CSM – Catalytic Static Mixer

Impact – Industrial Applications of Hydrogenations

Pharmaceuticals




Petrochemicals



Fine Chemicals



Polymers



Food Processing

R&D


Hydrogenation Reactor – Project Plan & Resources

3D Metal Printing

Additive Manufacturing



Metal Deposition




Electrodeposition & Cold Spraying

CFD & Experimental Fluid Dynamics



Fluid Dynamics



Flow Chemistry

Organic Chemistry & Reactor Engineering

Catalytic Static Mixers (CSMs)



Different designs:

→ maximize heat and mass transport for different reaction systems




Substrate Materials:

Ti-alloy, CoCr-alloy, Al-alloy, 316 SS, ...


Catalysts:

Ni, Pt, Pd, Cu, Au, Ag, ...

3D Metal Printing




Electroplating




Cold Spray




Nickel – Cold Spray





Platinum – Electroplating



Copper – Electroplating



Nickel - Electroplating





Palladium - Electroplating

Hydrogenation Reactor – Experimental Rig, Part 1



Prototype Flow Chemistry Reactor:

Mk 1: 4 catalyst zones, each 15 cm


(designed & built by CRD and CSIRO)




Proof of Concept – Hydrogenation using gaseous H₂




Catalyst Comparison:



We successfully tested this prototype reactor for the hydrogenation of alkenes, alkynes, carbonyls, nitro- and diazo-compounds, nitriles, imines, and halides, as well as bifunctional molecules such as the following:



Conclusions



- **Continuous Flow Processing** bridges the gap from laboratory / discovery scale to preparation / production scale, **mg** to **kg**, with minimum scale-up efforts.
- **Integrated Processing** allows for combination of several processing steps to form one continuous production line, e.g. purification, block co-polymers, ...
- **Efficient Processing** is achieved by using micro- and mm scale flow geometries
→ large surface to volume ratio, enhanced heat and mass transfer, higher STY

Acknowledgements

John Tsanaktsidis
Thomas Kohl
Ivan Martinez
Boris Bizet
Antoine Avril
Nenad Micic
Alan Young
Charlotte Genet

Simon Saubern
Oliver Hutt
James Gardiner
Dayalan Gunasegaram
Darren Fraser
Andrew Urban
Mike Horne
Jean-Pierre Veder

Almar Postma
Karin von Känel
Julien Rosselgong
John Chiefari
Kathy Turner
Ezio Rizzardo
San Thang
Graeme Moad

Xuan Nguyen
Stella Kyi
Maria Espiritu
Stuart Littler
Matthew Waterford
Trevor Hadley
Marta Rubio
Michael Batten

Thank you

CSIRO Manufacturing – FloWorks Centre for Industrial Flow Chemistry

Christian Hornung

Senior Research Scientist – Director, FloWorks Centre for Industrial Flow Chemistry

t +61 3 9545 2532

e christian.hornung@csiro.au

w www.csiro.au

m Bag 10, Clayton South

Victoria 3169

Australia

CSIRO MANUFACTURING

www.csiro.au

